型号：F-400A



真无线蓝牙耳机

开关

长按左右耳机MFB键约3秒开机
并伴有提示音。

手动开机

打开充电盒耳机自动开机。

自动开机

按键区域

长按左右耳机MFB键约5秒关机
并伴有提示音。（左右耳机TWS组队
状态，长按任何一边耳机都关机，左右
耳机同步关机）

手动关机

放入充电盒中关闭充电盒上盖，
耳机自动关机并开始充电

自动关机

蓝牙连接

从充电盒中拿起两个耳机



游戏音乐控制

L
- = 单击
- = 双击
- = 长按3秒(siri唤醒/退出)

R
- = 单击
- = 双击
- = 长按3秒(进入/退出)

通话语音控制



- = 单击
- = 双击
- = 双击

耳机恢复出厂设置

耳机开机状态下，长按5秒左或右耳机MFB键，
耳机清除TWS组队和设备配对记录成功。



- = 长按5秒

充电描述



基本参数

彩色灯带

当充电盒关闭时，左右指示灯将亮起并呼吸，这意味着
两个耳机处于充电模式。

备注： 当充电盒的电量低于5%时，LED闪烁四次，然后熄灭。
将停止为耳机充电。

规格

蓝牙版本：	5.3
充电端口：	Type-C
电源输入：	DC/5V
耳机电池容量：	40mAh/3.7V
音乐播放时间：	约4小时（80%音量）
支持协议：	A2DP/AVCTP/HSP/HFP
通话时间：	4.5小时（90%音量）
充电时间：	约1.5小时
充电盒电池容量：	400 mAh/3.7 V

注意事项

- 请在常温环境中存放以及使用本产品；
- 请勿将本产品长期暴露在雨中或潮湿的环境中；
- 请勿长摔，避免因跌落造成产品破坏；
- 请勿自行拆解，修理和改造本产品；
- 请使用额定电压的电源充电器充电；
- 擅自拆解将使保修失效。

- 充电盒及耳机内的电池为不可更换电池
- 不得暴露在诸如日照，火烤或类似过热的环境中

Model：F-400A



True wireless Bluetooth earphones

Switch

Press and hold the MFB button on the left and right
headphones for about 3 seconds to turn on the phone,
ring.

Manual startup

Turn on the charging case and the
headphones will automatically turn
on.

Manual startup

Key area

Press and hold the MFB button on the left and right
headphones for about 5 seconds to turn off the device,
accompanied by a beep, (TWS teaming status for left
and right earphones, long press on either earphone to
turn off, and both earphones will turn off simultaneously)

Manual shutdown

Put it into the charging box and close
the upper cover of the charging box,
The headphones will automatically
shut down and start charging

Manual shutdown

Bluetooth connectivity

Pick up two headphones from the charging box





Game/Music Control

L
- = Click
- = Double click
- = Long press for three seconds (siri wake-up/exit)

R
- = Click
- = Double click
- = Long press for three seconds (enter/exit)

Call voice control



- = Click
- = Double click
- = Double click

Restore headphones to factory settings

When the headphones are turned on, press and hold the MFB button on the left or right headphones for 5 seconds to clear the TWS pairing and device pairing records.



- = Quick click 6 times

Charging description



Basic parameters



Colored light strip

Earpiece：when the charing case is closed ,The left and right indicator will light up and breathe, which means that the two earphones are in charging mode.

Remark：When the charging case has less than 5% power,LED1 flashes four times and then turns off.And will stop charging the earphones.

SPICIFICATIONS

Bluetooth version：5.3
Charging port: Type-C
Power input：DC/5V
Earbuds battery capacity: 40mAh/3.7V
Music playback time：About 4 hours (80% volume)
Support agreement：A2DP/AVCTP/HSP/HFP
Talk time: 4.5 hours (90% volume)
Charging time: about 1.5 hours
Charging case battery capacity: 400 mAh/3.7 V

Note

- Please store and use this product in a room temperature environment;
- Do not expose this product to rain or damp environments for a long time;
- Do not throw to avoid product damage caused by falling;
- Do not disassemble, repair, or modify this product on your own;
- Please use a rated voltage power charger for charging;
- Unauthorized disassembly will void the warranty.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- The batteries in the charging box and headphones are non replaceable.
- Do not expose to environments such as sunlight, baking, or similar overheating.